



Please read carefully before using and keeping it properly.  
We supply warranty within 12 months after purchase date for all qualified machines. During warranty, we will offer repair services and the free parts.- essential oil not included. Once the warranty period expires, repair services will be charged, please read the detailed items from the below warranty list.

## 1. Equipment Installation



① Pull out the whole atomizer head and essential oil bottle straight upward.



② Unscrew the essential oil bottle in the direction of the arrow, add the essential oil supplies and put it back into the atomizer head.

③ Press and hold the power button for 2 seconds to turn on the unit after putting the atomizer head back on.  
Note: Use Type-C power cable when device atomizer needs to be charged.

## 2. Product Parameter


- Size: 181×73×136mm
- Weight: 820g
- Voltage: 5V
- Capacity: 50ml×2
- Power: 7.5W
- Coverage: 100m<sup>3</sup>

## 3. Packing

Equipment×1, Type-C Power cable×1, User Manual×1

## 4. Button/Indicator Function Description

### Button Illustration:



### ① Power button:

Device on/off button, press and hold it for 2 seconds until you hear the beep.

### ② Atomizer head switching button:

Switch left and right atomizer heads.

### Indicator status:

Blue light on the left	Left atomizer head on (air pump direction shown by key)
Blue light on the right	Right atomizer head on (air pump direction shown by key)

### ③ Light button:

Press the button to turn it on and off.  
Ambient light status: Blue light at the bottom of the unit when turned on.

### ④ Time Setting Button:

Press the button to switch the timer.

Indicator status:	
One blue light	Timer 2 hours
Two blue lights	Timer 4 hours
Three blue lights	Timer 8 hours
Four blue lights	Timer 12 hours

### ⑤ Fragrance level Button:

Press the button to switch the fragrance level.

### Indicator status:

One blue light	Air pump on for 5 seconds and off for 180 seconds
Two blue lights	Air pump on for 10 seconds, off for 120 seconds
Three blue lights	Air pump on for 30 seconds, off for 90 seconds
Four blue lights	Air pump on for 60 seconds, off for 60 seconds

All four blue lights are off: The device is in APP mode .

Note: The default startup time is 12 hours, the perfume frequency is on for 30 seconds, stop for 90 seconds.  
The button does not have a week setting, the APP mode has a week setting (see Bluetooth operation instructions).



### ⑥ Charging Indicator:

Low battery: Flashing red light.  
Charging: Red light is always on.  
Fully charged: Green light is always on.

## 5. Anti-tilting alarm

Tilting or standing upside down may result in oil leakage. When the device is tipped more than 45°, the device emits a "drop" alarm. For 120 seconds, the air pump stops working and the device is placed upright again. The air pump can resume normal operation.



## 6. Bluetooth operating instructions

### ● Home page

Scan code to download and install the app "Scent Tech", start the APP, complete the beginner's guide, select Bluetooth mode to enter the home page, at this time the available devices column displays the available Bluetooth devices that have been plugged in within the Bluetooth range, click to select the available devices to enter the status page.

Tip: App permission configuration, including location services, Bluetooth connection, and sending notifications are allowed.



APP download

### ● Status page

- Status window: Displays the current working mode parameters and status, including time, week, Bluetooth connection status, etc.
- Operation status: With just one click, your mobile phone can turn on/off the device, turn on/off the light, and switch between the left and right atomizers;
- Operating mode: Displays the current operating mode

Click the working mode bar to enter the mode setting, you can set 5 groups of working modes respectively, click any mode bar to customize the setting of week, time period, frequency.

① Week setting: Customize the weekly working date.

② Time range setting: Customize the time range for adding incense.

Note: The value cannot be set across days (the end time cannot be later than the start time). If you want to set the value to work across 00:00, set the value to two consecutive periods at both ends. For example, if you want to set the value to work from 23:00 to 02:00, set the value to 23:00 to 23:59 and 00:00 to 02:00.

③ Frequency setting: The spatial fragrance concentration can be adjusted by controlling the fragrance frequency.

Enable duration: Step by 5 seconds. The maximum value is 60 seconds and the minimum value is 5 seconds.

Pause duration: Step by 5 seconds. The maximum value is 180 seconds and the minimum value is 60 seconds.

- Device address: Obtain the network location address after the device is successfully configured.
- Click on the top right corner for more: Rename your device.

## 7. Equipment Maintenance

If the equipment is not used for a long time, 95% industrial alcohol should be added into the refined oil bottle to clean the nozzle and other parts inside the equipment. **Tip: Maintain the equipment with 95% industrial alcohol at least every 1-2 months.**

Specific operation: add 95% industrial alcohol into the empty bottle, turn on the equipment and run for 10-15 minutes after, then turn off the equipment and pour the alcohol, then screw back the bottle to machine.

## 8. Warranty

1. The Warranty is suitable for new machine but not resell or second hand products.
2. Within 12 months after purchase date, Warranty is offered for all qualified machines. During warranty, we will offer repair services and the free parts but without essential oil.
3. The warranty card & purchase Invoice are needed if after service required. Please contact with us within warranty if any problems.
4. The following is not for free warranty service:
  - ① Damage & problems caused by Accidents & Fire.
  - ② Not use properly and wrong operation.
  - ③ If repaired by not professional person and make some parts damaged.
  - ④ Damaged during transportation.
  - ⑤ Without our warranty card.
  - ⑥ Without proper cleaning for a long time
  - ⑦ The machine work time out.
  - ⑧ Machines & Parts not from us.
  - ⑨ Machines not gotten from official channels.
  - ⑩ Send the machines back without permit from manufacturer.

## 9. Notice

1. Please read carefully before using and keeping it properly.
2. During transportation of the device, the bottle must be emptied to avoid leakage of essential oils and damage to the device.
3. When the equipment is loaded with essential oil, it must be kept upright and upward, and cannot be inverted or tilted, otherwise the essential oil will leak and damage the internal parts of the equipment.
4. Do not use overloaded power sockets, power cords and broken power plugs, otherwise your safety may be jeopardized and fire may be caused; Do not damage the lithium battery, otherwise it may lead to danger.
5. Please do not open the machine by yourself, if problems, please contact us promptly!

# TWO HEADS APRAY LUXURY SMART SCENT DIFFUSER

Instruction manual



Please read the manual carefully before use and keep it properly